


MODEL NUMBER SELECTION:

The model number will consist of a base number 99050 followed by two 2 digit numbers which represent the options listed in the following tables.



ORDERING INFORMATION

Specify:

1. Model 99050 Gauge Head Limit Switch Assembly
2. Number of Cam Switches
3. Tank Height
4. Accessories

TABLE I - (AB) NUMBER OF SWITCHES (S.D.P.T.)

Option #	Description
01	Two (2) Limit Switches
02	Four (4) Limit Switches
03*	Six (6) Limit Switches

* 91 feet or 27.7 meters maximum tank height

TABLE II - (CD) READING CONFIGURATION & TANK HEIGHT

OPTION #	READING	Tank Height		Gear Ratio
		Feet	Meters	
01	GROUND READING	13	3.9	10-1
02	GROUND READING	19	5.7	15-1
03	GROUND READING	26	7.9	20-1
04	GROUND READING	32	9.7	25-1
05	GROUND READING	39	11.8	30-1
06	GROUND READING	52	15.8	40-1
07	GROUND READING	65	19.8	50-1
08	GROUND READING	78	23.7	60-1
09	GROUND READING	91	27.7	70-1
10*	GROUND READING	104	31.6	80-1
11	ROOF READING	13	3.9	10-1
12	ROOF READING	19	5.7	15-1
13	ROOF READING	26	7.9	20-1
14	ROOF READING	32	9.7	25-1
15	ROOF READING	39	11.8	30-1
16	ROOF READING	52	15.8	40-1
17	ROOF READING	65	19.8	50-1
18	ROOF READING	78	23.7	60-1
19	ROOF READING	91	27.7	70-1
20*	ROOF READING	104	31.6	80-1

* Maximum four (4) limit switches

ACCESSORIES	
Part #	Adapter for Mounting Limit Switch Assembly
9905-10300	To Counter Housing on 92020, 92021 or 92030 Gauge Note 1.
9905-10290	To Counter Housing on 92006 or 94154 Gauge

Mount Kit Required for 92006, 92020, 94154 and 92021 for in field mounting

NOTES:

1) Order accessories separately to mount limit switch to appropriate gauge.
When ordering with a 92030 gauge, specify on the sales order if factory mounting is desired.

2) The accessory kit is not required when ordering a 92021 gauge which was ordered with the limit switch assembly. Specify on the sales order if factory mounting is desired.